

DB37-JST-245 Cable

RADIO PORT

- 1
- 20
- 2
- 21
- 3
- 22
- 4
- 23
- 5
- 24
- 6
- 25
- 7
- 26
- 8
- 27
- 9
- 28
- 10
- 29
- 11
- 30
- 12
- 31
- 13
- 32
- 14
- 33
- 15
- 34
- 16
- 35
- 17
- 36
- 18
- 37
- 19

- +13.8V
- RS232 RTS
- RS232 CTS
- RSTTL OUT
- FILTER OUT
- CI-V IN
- RS232 IN

- RS232 OUT
- FILTER IN
- PTT1 OUT
- PTT2 OUT
- CW OUT

- 6
- 1
- 2
- 3
- 4
- 5
- 7
- 8

GND

JRC-JST245

GND
+13.8V

TRX Audio IN

PTT2

TRX Audio OUT

CW

RS-232 TX


RS-232 RX

TRX Audio IN

TRX Audio OUT

- 1
- 14
- 2
- 15
- 3
- 16
- 4
- 17
- 5
- 18
- 6
- 19
- 7
- 20
- 8
- 21
- 9
- 22
- 10
- 23
- 11
- 24
- 12
- 25
- 13

ACC
DB25M



- 1
- 14
- 2
- 15
- 3
- 16
- 4
- 17
- 5
- 18
- 6
- 19
- 7
- 20
- 8
- 21
- 9
- 22
- 10
- 23
- 11
- 24
- 12
- 25
- 13

RS232
DB25M

